






7.





8.



9.



10.



❄ = 5°C

13658 000 00 Manual Installation WRT Dial 230 F86 OW

ENGINEERING
TOMORROW



Installation & User Guide

Danfoss *Icon*™ Dial Room Thermostat

VICUY10F/088N3653

www.icon.danfoss.com