

















Set Up the Polycom® EagleEye™ Producer







4 Polycom RealPresence® Group 300/310/500




4 Polycom RealPresence® Group 700




5






6








Refer to the Polycom EagleEye Producer User Guide for more information.



1 ⏶ 5 seconds
LED: fast blue blink



2



3 To exit ⏶ press any key on remote except up/down arrows. LED: blue

